


SEテール駆動オートロッドAssy
SE tail drive auto-rotation assembly

純正オートロッドAssy
(0402-318, ¥700)
(0402-016, ¥3000)

Pure auto rotation assembly

ストップリングS-12 (2508-003, 5J ¥500)
Stop ring S-12

SEメインギヤ77T
(0402-574, ¥7800)
SE main gear77T



●純正又はSEメインギヤに組み込み、オートロト時のテール駆動をさせます。

過大なラダー操作をした時にもメインローターの回転が下らない安全な構造になっています。

使用方法

S-12ストップリングを取り外し、図の順に取付けます。

硬さは、ワッシャーの枚数で調整します。

◎ ローターなしでヘッドを勢いよく手で回した時、1~2秒してからテールが回転する位が良いでしょう。

★ ホールド時、リポリューションミキシングがゼロになる様、送信機側でセッティングして下さい。

● Assemble the auto rotation assembly in the genuine or SE main gear, and drive the tail in auto rotation.

When excessive rudder control is done, such a safe structure that the rotation speed of the main rotor is not decreased in adopted.

How to use

Remove a S-12 stop ring and mount the parts in the order shown in the illustration below.

Adjust the hardness by increasing or decreasing the number of washers.

◎ It is good that the tail can rotate in one or two seconds when rotating the head strongly by your hand without the rotor.

★ Set the revolution mixing at the side of the transmitter so that it can become zero on hold.



技術で拓く真心のクオリティー

ヒロボー株式会社

営業本部

HIROBO LIMITED